



SCALE AND CONTROL INC.

Toll Free: 888-239-0552

Tel: 713-352-3071

sales@scaleandcontrol.com

Calibration Process

1. Turn on machine
2. From the home screen on app click the **menu** button
3. Select **Calibration**
4. Under **Attachment** tap the pen icon and select attachment
5. You can do up to 5 different calibrations with 5 different weights (2 is recommended, one with no weight and one with a known weight of at least 70% of machines full capacity)
6. After selecting your attachment and points click START
7. On the first load input a load of 0 and press SET
8. Go through steps on tablet
9. Once complete the same window will pull up for a new weight
10. Input the weight of your known load
11. Continue this process if you are doing more than 2 points
12. Once complete a window will pop up saying calibration complete
13. Click **OK** and exit out
14. Now your tablet and system is set up and ready to use

NOTE-Lift and lower bucket at the machine's normal speed, but do so without causing the bucket to slam as it can knock the calibration off

FOR QUESTIONS OR CONCERNS CALL TECHNICAL SUPPORT 888-239-0552