



**SCALE AND CONTROL INC.**

Toll Free: 888-239-0552

Tel: 713-352-3071

[sales@scaleandcontrol.com](mailto:sales@scaleandcontrol.com)

## Setting Up SCI App

**NOTE:** Steps below are only necessary if you are A. using your own Samsung tablet, or B. replacing the tablet. If you purchased a tablet from SCI, it will be pre-set up.

1. From the home page tap on the "SCI" icon
2. Open the menu and click the gear symbol (settings)
3. Set up units how you would like by tapping the upside-down triangle next to the word
4. Click **Submit**
5. Tap on **System**
6. If using Zebra Printer or desktop Printing slide to turn on so system can communicate
7. If weighing in tons tap on Unit Rounding and change to 2
8. Scroll down to company info. And input your company's info.
9. Click **Submit**
10. Tap on **EEPROM** and edit transducer Piston Volt Min. to 480
11. Leave the rest alone and click submit
12. Click the back arrow on the top left-hand side
13. Go back into your menu
14. Tap on **Attachments**
15. Click the add button on top right-hand side
16. Under **Long Name** put what kind of attachment you have
17. Turn on Scale enabled and select image if wanted
18. Click **Submit**
19. Go back to menu
20. Tap on **Customers**
21. Click add
22. Put in customer info. And click submit (can add up to 200 customers)
23. Go back into menu
24. Tap on **Materials**
25. Click add
26. Put in material, select unit type and sales unit
27. Click submit (can do up to 200 materials)
28. Go back to **menu**
29. Select **Home**

Your WLS555 Scale is almost complete. Calibration is the last procedure to do.

**FOR QUESTIONS OR CONCERNS CALL TECHNICAL SUPPORT [888-239-0552](tel:888-239-0552)**