



## Setting up Samsung Tablet

**NOTE:** *If you purchased a tablet from SCI, when shipped it will be pre-set up, only use this if you are, A. using your own Samsung tablet, or B. replacing the tablet*

1. Take tablet out of box
2. Put battery in back and leave in
3. Power up tablet by holding the top button on right side of tablet
4. Go through initial set-up (don't sign into email or Wi-Fi)
5. For device name put customer or company name (ex: Johns Gravel)
6. Once initial device set-up complete hold down on home screen with finger
7. Delete bixpy home and far right page
8. Remove all apps from home screen
9. Connect to good Wi-Fi, go back to home screen
10. Swipe down on home screen, open play store
11. If asked to sign in; Username: [updatetablet805@gmail.com](mailto:updatetablet805@gmail.com) Password: [Weight4It](#) (Capital W and I)
12. At the search bar tap the menu line on the left of search bar
13. Select **My Apps & Games**
14. Update **ONLY Chrome** if option available
15. Exit out of play store
16. Swipe down on home screen, hold setting icon with finger, app will go to home screen
17. Open **Settings** application
18. Under **Sounds and Vibrations** turn off all icons
19. Under **Notifications** turn off all apps and app icon badges
20. Under **Display** turn brightness all the way up, turn off Auto-brightness, change screen time out to 30 minutes, turn on **Block accidental Touches**
21. Under **Advanced Features** turn on touch sensitivity and turn off all else
22. Under **Lock-Screen** turn off notifications
23. Under **Accessibility** turn off single tap mode
24. Under **General Management** tap **language & Input**; move pointer speed to fast
25. Under **Soft Ware Update** turn all off
26. Under **About Tablet** tap on software information, tap on build number 7 times to unlock developer options
27. Under **Developer Options** turn everything OFF except show touches and turn on **Show Touches**
28. Now turn on your machine to enable power to the WLS555 Scale
29. Go into **Connections** under **Settings**
30. Tap on **Wi-Fi**



**SCALE AND CONTROL INC.**

Toll Free: 888-239-0552

Tel: 713-352-3071

sales@scaleandcontrol.com

31. Click on scale (ex: [SCI-Scale-#####](#))
32. Click Show Password and Auto-Reconnect
33. Password is [Weight4It](#) ---- Capital W and I
34. After tablet is connected to the scale's Wi-Fi tap the home button (bottom of tablet)
35. Swipe down on home screen to open all apps
36. Click window that says [Google](#), and open [Chrome](#)
37. Under the address bar type in [www.wls555.local/](http://www.wls555.local/)
38. Once website opens tap on the [3 dots](#) on the top right-hand side of screen
39. Click [Add to Home Screen](#)
40. Confirm [Add to Home Screen](#)

Tablet is now set up.