



SCALE AND CONTROL INC.

Toll Free: 888-239-0552

Tel: 713-352-3071

sales@scaleandcontrol.com

USB Stick Update Instructions

1. Turn Machine on.
2. Use a phone or notepad to write down all info on the SCI app (Material, Customers, Calibration, Attachment lists and System Settings) - **IMPORTANT IN CASE ALL INFO DELETES.**
3. Insert USB thumb drive into USB port on Machine. (SET A TIMER FOR 20 MINUTES)
4. At 20 minutes remove USB and turn machine off
5. Once all lights on system are off power back up your machine
6. On tablet go to **SETTING, APPS, CHROME, STORAGE, CLEAR CACHE**
7. Go back to home screen
8. Go to **CHROME**, click the 3 dots at top right-hand side of screen.
9. Click **HISTORY**, click on x on all previous sites.
10. Once complete connect tablet to scale and go to chrome, type in the address bar **www.wls555.local/**
11. Validate all info on the SCI app is correct. (if any info is missing input the correct info from your phone or notepad that has all your system info and make sure to click save)
12. Complete.

Finishing

1. Connect USB thumb drive to PC
2. Open file explorer
3. Send the .txt file to **support@scaleandcontrol.com** with subject of WLS Update - S/NXXXXX (XXXX is the number you see when connecting to Wi-Fi)

FOR QUESTIONS OR CONCERNS CALL TECHNICAL SUPPORT 888-239-0552